

# Marz & Flite Operating Instructions

This Ergonomic chair is produced with comfort and support as its primary aim. Contributing to this aim is the extra large seat fitted with a seat slide. The Marz has a double curved back fitted with a free float mechanism with an 8 degree forward tilt. This chair also has weight tension control, gas height adjustment and an independent ratchet back with height adjustability. All this gives a level of adjustment that ensures support throughout every movement. Suitable for 24/7 use when upholstered in 24/7 fabric. This versatile range of chairs should meet the needs and requirements of the most discerning user.

## Adjusting The Marz or Flite

- A Gas height adjustment: Lift lever to raise or lower your chair
- B Body weight tension control: Turn clockwise to increase tension or anticlockwise to decrease tension
- C Tilt control lever: Lift lever to activate free float or push lever down to lock chair in desired working position
- D Seat depth adjustment: Lift lever and slide seat in or out to suit the height of person
- E Arm height adjustment: Push button and lift arm to suit user
- F Seat width adjustment: Release lever from under the seat to adjust the seat width to suit the user then lock Marz Models Only
- G Back height adjustment: With both hands lift the back up to the desired position to suit the users lumbar region



# Titan Operating Instructions

The contoured back of this well equipped chair not only has a stylish design, but gives added support to your back, whilst you are sitting in comfort. This versatile chair with push button synchronised mechanism, side tension control, forward anti-tilt and anti-shock system gives comfort and assured reliability to the user.

## Adjusting The Titan

- A Gas height adjustment: Lift lever to raise or lower you chair
- B Body weight tension control: Turn clockwise to increase tension or anti-clockwise to decrease tension
- C Tilt control lever: Push button in to operate or push button again to lock chair in desired working position
- D Arm height adjustment: Push button and lift arm to suit user
- E Back height adjustment: With both hands lift the back up to the desired position to suit the users lumbar region



# Titan Two Operating Instructions

## Adjusting The Titan Two

- A Gas height adjustment: Lift lever to raise or lower your chair
- B Body weight tension control: Turn clockwise to increase tension or anti-clockwise to decrease tension
- C Tilt control lever: Push lever forward to lock or push lever backwards to activate free float
- D Arm height adjustment: Push button and lift arm to suit user
- E Back height adjustment: With both hands lift the back up to the desired position to suit the users lumbar region



# 9000 Range Operating Instructions

Elegant simplicity and beautifully balanced proportions, the 9000 range is practical, comfortable and hard-wearing. Suitable for 24 hour use, this collection is bound to keep even the busiest operator happy!

## Adjusting The 9000

- A Gas height adjustment: Lift lever to raise or lower your chair
- B Body weight tension control: Turn clockwise to increase tension or anti-clockwise to decrease tension
- C Tilt control lever: Push lever forward to lock or push lever backwards to free float
- D Arm height adjustment: Push button and lift arm to suit user
- E Back height adjustment: With both hands lift the back up to the desired position to suit the users lumbar region



# 9000 Budget Operating Instructions

## Adjusting The 9000 Budget

- A Gas height adjustment: Lift lever to raise or lower your chair
- B Body weight tension control: Turn clockwise to increase tension or anti-clockwise to decrease tension
- C Tilt control lever: Push lever forward to lock or push lever backwards to free float
- D Arm height adjustment: Push button and lift arm to suit user
- E Back height adjustment: With both hands lift the back up to the desired position to suit the users lumbar region



# Mayfair Operating Instructions

Our exclusive and widely popular Mayfair collection offers excellent design features, ergonomic shaping to the back for support and comfort, and superior quality throughout the entire chair range. There are eight style variations, four of which are shown here. When you add the optional extras you have a range to fit any executive environment.

The optional luxury of leather upholstery provides significant advantages.

## Adjusting The Mayfair

- A Gas height adjustment: Lift lever to raise or lower your chair
- B Body weight tension control: Turn clockwise to increase tension or anti-clockwise to decrease tension
- C Tilt control lever: Push lever down to release the lock or lift lever up to free float
- D Arm height adjustment: Push button and lift arm to suit user



# Westminster Executive Operating Instructions

## Adjusting The Westminster

- A Gas height adjustment: lift lever to raise or lower your chair
- B Body weight tension control: Turn clockwise to increase tension or anti-clockwise to decrease tension
- C Tilt control lever: push lever down to release the lock or lift lever up to free float



# 3000 Range Operating Instructions

Strong and sophisticated, and with numerous arm and mechanism options, the 3000 collection grants established style with all-day support and comfort.

## Adjusting The 3000

- A Gas height adjustment: Lift lever to raise or lower your chair
- C Tilt control lever: Lift lever to operate the back rake or push lever down to lock chair in desired working position
- D Seat depth adjustment: Lift lever and slide seat in or out to suit the height of person: Optional for this range
- E Arm height adjustment: Push button and lift arm to suit user
- G Back height adjustment: With both hands lift the back up to the desired position to suit the users lumbar region



3001

# Solar Operating Instructions

## Adjusting The Solar

- A Gas height adjustment: Lift lever to raise or lower your chair
- B Body weight tension control: Turn clockwise to increase tension or anti-clockwise to decrease tension
- C Tilt control lever: Lift lever to operate the back rake or push lever down to lock chair in desired working position
- D Seat depth adjustment: Lift lever and slide seat in or out to suit the height of person
- E Arm height adjustment: Push button and lift arm to suit user
- G Back height adjustment: With both hands lift the back up to the desired position to suit the users lumbar region
- H Seat tilt: Lift lever and tilt seat to desired position then push lever down to lock
- I Lumbar support: Pump by hand to increase lumbar support or twist valve to reduce



SR03

# 56 Operating Instructions

Functional, stylish good looks, and built to last.

This new addition to our task chair range offers solutions to your operator's needs.

## Adjusting The 56

- A Gas height adjustment: Lift lever to raise or lower your chair
- B Seat tilt: Lift lever and tilt seat to desired position then push lever down to lock
- C Tilt control lever: Lift lever to operate the back rake or push lever down to lock chair in desired working position
- E Arm height adjustment: Push button and lift arm to suit user
- G Back height adjustment: Release handwheel Adjust back height and tighten handwheel



# BU Entry Level Operating Instructions

## Adjusting The BU10 / BU20

- A Gas height adjustment: Lift lever to raise or lower your chair



# CF Operating Instructions

Following all the basic principles that you would expect from an Operator range, the CF collection is hard-wearing, hard-working, and a hard act to follow.

## Adjusting The CF

- A Gas height adjustment: Lift lever to raise or lower your chair
- C Tilt control lever: Lift lever to operate the back rake then push lever down to lock chair in desired working position
- D Seat depth adjustment: Lift lever and slide seat in or out to suit the height of person: Optional for this range when used with a Euro Mechanism
- J Back height adjustment: Release handwheel Adjust back height and tighten handwheel



# UPC Operating Instructions

An established range, the UPC collection combines the latest concepts in ergonomic task orientated seating along with clean elegant lines. A collection that represents excellent value for money

## Adjusting The UPC

- A Gas height adjustment: Lift lever to raise or lower your chair
- C Tilt control lever: Lift lever to operate the back rake or push lever down to lock chair in desired working position
- D Seat depth adjustment: Lift lever and slide seat in or out to suit the height of person
- E Arm height adjustment: Push button and lift arm to suit user
- G Back height adjustment: With both hands lift the back up to the desired position to suit the users lumbar region
- H Seat tilt: Lift lever and tilt seat to desired position then push lever down to lock
- I Lumbar support: Pump by hand to increase lumbar support or twist valve to reduce

